

UG-092 / UG-093 / UG-094 UL レジャーシート S / M / L

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は屋外用レジャーシートです。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止し、ご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

スペック

UG-092 UL レジャーシート S

●材質:20Dシリコンナイロンリップストップ・耐水圧3,000mmミニマム●サイズ:1,970×1,000mm●収納サイズ:90×35×110(h)mm●重量:96g

UG-093 UL レジャーシート M

●材質:20Dシリコンナイロンリップストップ・耐水圧3,000mmミニマム●サイズ:1,970×1,500mm●収納サイズ:110×35×160(h)mm●重量:140g

UG-094 UL レジャーシート L

●材質:20Dシリコンナイロンリップストップ・耐水圧3,000mmミニマム●サイズ:1,970×1,970mm●収納サイズ:130×35×170(h)mm●重量:180g

安全上の注意事項 ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

△危険 明らかに生命に関わる重大な事故が予測される行為を示します。

●本製品は難燃性ではありません。本製品の上、及び近くでは熱源や裸火は絶対に使用しないでください。また引火性の燃料やガスの使用もおやめください。

△警告 取扱いを誤った場合、使用者が死亡または重傷を負う可能性があることを示します。

●ご使用の前に本製品を点検し、各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止し、お買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。

●気象状況には常に細心の注意を払い、風の強い時や悪天候が予想されるときは速やかに撤収して安全な場所へ避難してください。また川の氾濫やがけ崩れなどの危険が予想される場所には設置しないでください。

△注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

●本製品は屋外でのレジャー活動時に地面に敷いて使用することを目的としています。本来の用途以外に使用しないでください。

●本製品は常設用ではありません。

●日差しにより製品の表面は低温やけに発展するほどの高温になります。十分ご注意ください。

●角のある石や折れた木の枝など鋭利なものがない平坦な場所で使用してください。

●設営・撤収の際は、風に飛ばされないよう製品をしっかりと掴んで作業してください。

●薬品などが付着するとコーティングが破壊され耐水圧が異常低下してしまう場合があります。この症状と判断された場合、製品の保証が出来なくなりますのでご注意ください。

●防水性の高い生地を使用しておりますが、地面の水溜りなどへ長時間接触していると雨水が浸み込む場合があります。

●本製品の上で小型テーブルなどを使用する際は、脚部の裏にバリやさざくれなど鋭利になっていないか確認してください。また、本製品の上で物を引きずる、生地を引張りすぎる、重量物を載せるような行為はお控えください。生地が破れる原因となります。

●本製品は材質的に滑りやすくなっています。人や物が転倒しケガや本体破損、物品破損のおそれがあります。ご注意ください。

メンテナンスについて

●長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止し、お買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。

●本製品は材質的にしづが発生しやすくなっています。予めご了承ください。

●樹液が付着してしまうときれいに除去することはできません。樹液が垂れそうな木の下を避けて設営してください。溶剤などにより無理に除去すると生地やコーティングを傷めます。

●生地の特性を考慮し、できる限り色移りし難い加工と配色パターンを採用していますが、保管状態などにより、色移りが発生する場合があります。ご了承ください。また、濡れたままの保管は避けください。

●濡れたまま保管すると、カビや悪臭、生地の色移り、生地の劣化などのトラブルの原因になりますので、使用後は風通しの良い日陰で十分に乾燥し、柔らかいブラシなどで泥汚れを落としてから保管してください。

●汚れがひどい場合は、本製品に記載の洗濯表示に従い洗濯してください。

●高温多湿を避け、直射日光の当たらない風通しのよい場所に保管してください。

●次回の使用に備え、付属品も含め、上記の通り十分に保守、点検してください。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。1.素材の経年劣化による損害など商品の寿命 / 2.改造および粗雑な取扱いによる故障 / 3.取扱説明書で禁止されている取扱いによる故障 / 4.不測の事故による商品の故障 / 5.その他製造上の欠陥以外による製品の故障 / 6.ゴミやさびによる故障 / 7.分解したことによる不具合の発生または破損 / 8.落下やその他の衝撃による部品の変形や破損による不具合 / 9.摩擦によるバーツの変化及びそれによる故障 / 10.他社製品との組み合わせによる故障

修理について

●本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。●修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。●修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。●修理品の運賃並びに修理費については以下のように規定させていただきます。1.保証対象の場合:往復運賃並びに修理費は弊社にて負担いたします。/ 2.保証対象以外の場合:往復運賃並びに修理費は、お客様のご負担とさせていただきます。

**UG-092 / UG-093 / UG-094
UL Leisure Sheet in S / M / L**

Thank you for purchasing a Snow Peak product. This product is an outdoor picnic rug for camping. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Specifications**UG-092 UL Leisure Sheet in S**

- Material: 20D Silicon Nylon Ripstop Waterproof Rating: 3,000mm minimum •Size: 1,970×1,000mm / 77.6"×39.4"
- Storage Size:90×35×110(h)mm / 3.5"×1.4"×4.3"(h) •Weight: 96g / 3.4 oz

UG-093 UL Leisure Sheet in M

- Material: 20D Silicon Nylon Ripstop Waterproof Rating: 3,000mm minimum •Size: 1,970×1,500mm / 77.6"×59"
- Storage Size:110×35×160(h)mm / 4.3"×1.4"×6.3"(h) •Weight: 140g / 4.9 oz

UG-094 UL Leisure Sheet in L

- Material: 20D Silicon Nylon Ripstop Waterproof Rating: 3,000mm minimum •Size: 1,970×1,970mm / 77.6"×77.6"
- Storage Size:130×35×170(h)mm / 5.1"×1.4"×6.7"(h) •Weight: 180g / 6.3 oz

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.**⚠ DANGER / Misuse could easily result in a serious accident or death.**

- This product is not flame-retardant. Do NOT use open fire or any heat source on or near this product. Do not use flammable fuel or gas.

⚠ WARNING / Misuse could result in serious injury or death.

- Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair.
- Pay close attention to the weather. If there are strong winds or extreme weather is in the forecast, pack up camp immediately and evacuate to a safe place. Do not lay this product in places where there is a risk of flooding, landslide, or other hazard.

⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.

- This product is designed to be used for outdoor activities by laying it on the ground. Do not use this product for any other purposes.
- This product is not intended to be in permanent use.
- Sunlight can cause the surface of the product to heat up, potentially causing low-temperature burns.
- Use this product on a flat place with no sharp objects such as rocks with sharp edges or broken branches.
- Firmly hold the product when assembling and disassembling. Unexpected accidents may occur due to the (frame/ pole) ends recoiling, etc., so ensure that the surroundings are safe, with no other people in the vicinity. Always assemble/disassemble this product with two or more people.
- The coating may be damaged by chemicals, which cause the water pressure resistance to decrease abnormally. Please note that the product cannot be subject to warranty if damaged by chemicals.
- Although this product is made of highly waterproof fabric, rainwater may soak into it if it is in contact with water pools on the ground for a long time.
- When using a small table on this product, check for any burrs and rough, sharp parts on the back of each leg. Avoid dragging objects on top of this product, forcefully tugging at the fabric, or placing heavy products on this product. It may cause the fabric to tear.
- This product uses materials that can be slippery. It may cause people and/or objects to fall over, leading to injuries or damage to this product or other objects. Be cautious when handling.

Maintenance

- Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair.
- This product uses materials that are prone to wrinkling. Please note that beforehand.
- Sap cannot be easily removed. Do not set up this product under trees that frequently drop sap. If the sap is forcibly removed with a solvent, etc., the fabric or coating may be damaged.
- Considering the material characteristics, we adopted processing and color patterns that will result in less color migration. However, depending on storage conditions, slight color migration may occur. Do not store the product while it is wet.
- Before storage, the product should be cleaned and dried sufficiently. If the product is stored when wet, the build-up of mold, bad odors, color migration, and material deterioration will occur. Dry the product sufficiently in a breezy and shaded area and clean the surface with a soft brush before storing.
- If this product is dirty, wash it by following the washing instructions provided on this product.
- Please store in a well-ventilated area away from direct sunlight, high temperatures, and humidity.
- Carefully maintain and inspect the product (including accessories) as per the above instructions in preparation for the next time the product will be used.

Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following: 1. Material deterioration caused by age. / 2. Damage caused by modifications or rough handling. / 3. Damage caused by inappropriate use not mentioned in the instruction manual. / 4. Damage caused by unexpected accidents. / 5. Any damage other than defects in the manufacturing process. / 6. Damage caused by dust or rust. / 7. Damage and defects caused by dismantling the product. / 8. Damage and defects caused by dropping, jolting or other shocks. / 9. Deterioration or failure of parts due to friction. / 10. Damage caused by the use of the product in combination with another manufacturer's products.

Repair

- If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service. •When you request repairs, please make sure that the product is dry and clean. •Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred. •Transportation and repair costs are determined as follows: 1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak. / 2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.