


ST-032BSR ベースプレートスタンド L/M

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は、焚火台と焚火台ベースプレートを併用時の、焚火の熱による芝へのダメージを軽減するスタンドです。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止しご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

セット内容 (各部の名称)



スペック

- 材質:スチール(カチオン電着塗装)
- サイズ:440×440×107(h)mm
- 収納サイズ(1/2枚):619×20×107(h)mm
- 重量:1.8kg

安全上の注意事項 ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

⚠ 危険 明らかに生命に関わる重大な事故が予測される行為を示します。

- 焚火台の取扱い説明書をよく読んでから、ご使用ください。

⚠ 注意 ケガや本体破損、物品破損として拡大被害の原因となる行為を示します。

- 傾斜地や不安定な場所でのご使用は本体の転倒などにつながるおそれがありますので避けてください。また設置した状態でガタツキがないことを確認の上ご使用ください。●表面の塗装は耐熱性ではありません。変色または剥がれる場合があります。●本体はスチール製です。ご使用によりサビがでる場合があります。●本製品は端部処理を施しておりますが、取扱には十分ご注意ください。●本製品のスリット部やプレートとプレートの上に指や手を入れないでください。ケガをするおそれがあります。●無理な取り扱いがケガやヤケド、製品の破損につながるおそれがありますのでご注意ください。●後かたづけの際は本体が十分冷めていることを確認のうえ行ってください。


その他の注意事項

- 公園や河川敷、キャンプ場といった公用地で焚火を行う際は各自自治体や管理者に確認してください。焚火や火気などの使用が禁じられている場所では絶対に使用しないでください。

組み立てと使用方法


ベースプレートスタンド L/M は、
焚火台L + 焚火台ベースプレートL もしくは、
焚火台M + 焚火台ベースプレートM との組み合わせで
使用することができます。

①スリットを合わせる





A、Bプレートのスリット同士を合わせます。

②スタンド向きと設置





使用する焚火台のサイズが刻印されている方向を上に向け、焚火を行う平坦な場所に設置します。

③ベースプレートを載せる



ベースプレートの各穴に対して、スタンドのツメ2点が接するように載せます。

④焚火台を載せる



ベースプレートの穴から見える、スタンドのツメの横の凹みに焚火台の脚を合わせてください。

メンテナンスについて

- 硬い素材のたわしや磨き粉で洗淨しないでください。●保管の際は高温多湿な場所を避け、通気性のよい場所に保管してください。●水分や塩分などが付着した場合は、速やかに拭き取り、十分に乾燥させてください。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合には修理できない場合もありますので予めご了承ください。1.素材の経年劣化による損害など商品の寿命 / 2.改造および粗雑な取扱いによる故障 / 3.取扱説明書で禁止されている取扱いによる故障 / 4.不測の事故による商品の故障 / 5.その他製造上の欠陥以外による製品の故障 / 6.ゴミやさびによる故障 / 7.分解したことによる不具合の発生または破損 / 8.落下やその他の衝撃による部品の変形や破損による不具合 / 9.摩擦によるパーツの変化及びそれによる故障 / 10.他社製品との組み合わせによる故障

修理について

- 本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。●修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。●修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。●修理品の運賃並びに修理費については以下のように規定させていただきます。1.保証対象の場合:往復運賃並びに修理費は弊社にて負担いたします。 / 2.保証対象以外の場合:往復運賃並びに修理費は、お客様のご負担とさせていただきます。

不明な点やお気付きの点がございましたら、
販売店様または弊社ユーザーサービスまで
お問い合わせください。

スノーピークユーザーサービス
☎0120-010-660(9:00~17:00)
Email:userservice@snowpeak.co.jp



株式会社スノーピーク
〒955-0147 新潟県三条市中野原456
Tel. 0256-46-5858 / Fax. 0256-46-5860
www.snowpeak.co.jp

MADE IN JAPAN

ST-032BSR Base Plate Stand L/M

Thank you for purchasing a Snow Peak product. This product is a Base Plate Stand for Pack & Carry Fireplace L/M. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Contents (Name of the Parts)



Specifications

- Material: Steel (Cationic electrodeposition coating)
- Dimensions: 440×440×107(h)mm / 17.3"×17.3"×4.2"(h)
- Dimensions (each): 619×20×107mm / 24.4"×0.8"×4.2"
- Weight: 1.8kg / 4.0 lbs

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

⚠ DANGER / Misuse could easily result in a serious accident or death.

- Please read the instruction manual of Pack & Carry fireplace carefully before use.

⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.

- Avoid using fireplace in sloping places or unstable places, as it may lead to failing of the fireplace.
- The painting on surface is not heat-resistant. It may be discolored or peeled off.
- This product is made of steel. It may rust after use.
- This product has been subjected to edge treatment, but please be careful when handling it.
- Do not intentionally insert your fingers or hands into the slit of this product or between the plates. Failure to do so may result in injury.
- Unreasonable handling may result in injury, burns and damage to the product.
- Please make sure that the product is sufficiently cooled off when cleaning up.


Other Notes

- Please check with local governments and administrators when putting open fire in public places such as parks, riversides, and camping grounds. Do not use this product where open fire is prohibited.

How to Assemble


Pack & Carry Fireplace Base Plate Stand L/M can be used with
Pack & Carry Fireplace L + Pack & Carry Fireplace Base Plate L
or
Pack & Carry Fireplace M + Pack & Carry Fireplace Base Plate M

①Align the slits





Fit the slits of the plates of A and B together.

②Direction and installation of the stand





Place the letter that corresponds to the size of the Pack & Carry Fireplace in use facing upward. (L for Large, M for Medium)

③Put the Base Plate on



Put the Base Plate as 2 notches of Base Plate Stand contact with each hole of Base Plate.

④Put the Fireplace on



Place the feet of Fireplace on the dent next to the notches on Base Plate Stand

Maintenance

- Do not wash with hard material scrubbing or polishing powder.
- When storing, avoid hot and humid places and keep in a place with good ventilation.
- When moisture or salt adhere, please wipe off and dry it thoroughly.

Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following: 1. Material deterioration caused by age. / 2. Damage caused by modifications or rough handling. / 3. Damage caused by inappropriate use not mentioned in the instruction manual. / 4. Damage caused by unexpected accidents. / 5. Any damage other than defects in the manufacturing process. / 6. Damage caused by dust or rust. / 7. Damage and defects caused by dismantling the product. / 8. Damage and defects caused by dropping, jolting or other shocks. / 9. Deterioration or failure of parts due to friction. / 10. Damage caused by the use of the product in combination with another manufacturer's products.

Repair

- If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service.
- When you request repairs, please make sure that the product is dry and clean.
- Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred.
- Transportation and repair costs are determined as follows: 1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak. / 2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.

Snow Peak USA, Inc.

404 NW 23rd Avenue, Portland, Oregon 97210, USA
Tel. +1 (503) 461-0781 / Instagram. @snowpeakusa
Email. info@snowpeak.com / www.snowpeak.com

Snow Peak, Inc.

456, Nakanohara, Sanjo-Shi, Niigata 955-0147 Japan
Tel. +81 256-46-5858 / Fax. +81 256-46-5860
www.snowpeak.co.jp